Quick Start Guide

To power up the rTB:

1. Push the Power button.
   The blue LED should light up.

2. Connect the Thunderbolt 3 cable
   to your Mac or PC.

Use the browser on the system and go to: https://www.pronology.com/rtb-drivers/

From the list, select the appropriate rTB driver download and launch

rTB DRIVER DOWNLOADS

Please see the Quick Start Guide for instructions to connect your rTB.

WINDOWS

Windows 10 64 bit

Download

Windows 8/10 32 bit

Download

arcSAP RAID Management Utility

Download

MAC

OSX Catalina and higher

Download

OSX Sierra, High Sierra, and Mojave

Download

arcSAP RAID Management Utility

Download